
## No Mess Auto Drinker Instructions #540075






2. Place red washer over threads. Then thread brass nut onto threads.










DREMIER

4. (*left*) Finish by adding the push-fit legs to the bottom of the drinker.



© Copyright 2016, Premier1Supplies. All rights reserved.