

# How to Repair Netting



www.premiersupplies.com • 800-282-6631 • Washington, IA 52353

## **If a horizontal wire is broken:**

1. Disconnect from power source.
2. Cut out the bad portion of the horizontal wire with a pair of scissors.
3. Measure out an appropriate amount of the replacement conductive or non-conductive material.
4. Tie the replacement material to one side of the break with a square knot. (If possible, twist the metal filaments together of the original material and the splicing material before the knot is made.)
5. Repeat the twisting, tying and knot step on the remaining side of the break.
6. Place a brass ferrule over each of the square knots and clamp together with a pair of pliers.

## **Additional repair kits are available:**

- #201700 - RaccoonNet, VersaNet, VersaNet Plus, HogNet, ElectroNet, ElectroNet Plus and E'Net (nets with 13mm/.51" posts).
- #201710 - PoultryNet, PoultryNet Plus, ElectroStop, ElectroStop Plus, E'Stop and Pos/Neg ElectroStop (nets with 15mm/.60" posts).
- #201720 - Horse QuikFence.
- #201721 - Pig QuikFence, Cattle QuikFence and Deer QuikFence.
- #201730 - ElectroFence, PermaNet and PermaNet Plus (nets with 19mm/.75" posts).