

BlitzLight #132300

www.premier1supplies.com • 800-282-6631

Pliers

Tools needed:

Before going out to the field:

- Remove nut and washers from one of the bolts.
- Place ground probe along bolt head. Place washer over head/probe.
- Slide ground wire (green) clip over bolt. Follow with second washer and nut. Tighten. Do not over tighten (this can cut the conductor).

Attaching BlitzLight to fence:

- Make sure the fence is not energized (turn off energizer).
- Hang the BlitzLight on the fence (via clip).
- Using the second bolt/washer combo—place the bolt next to the conductor you're attaching the light.
- Place washer over bolt, follow with the red fence clip, second washer and nut. Tighten. Depending on conductor diameter, you may want to wedge the conductor between washers rather than the bolt head and washer. Do this with twine.
- Screw the nut down tight.
- Insert ground probe into ground.



© Copyright 2016, Premier1Supplies. All rights reserved.