

How to Repair Netting

If a horizontal wire is broken—

1. Disconnect from power source.
2. Cut out the bad portion of the horizontal wire with a pair of scissors.
3. Measure out an appropriate amount of the replacement conductive or non-conductive material.
4. Tie the replacement material to one side of the break with a square knot. (If possible, twist the metal filaments together of the original material and the splicing material before the knot is made.)
5. Repeat the twisting, tying and knot step on the remaining side of the break.
6. Place a brass ferrule over each of the square knots and clamp together with a pair of pliers.

© Copyright 2017, Premier1Supplies.
All rights reserved.



Repair Kit #201700

- E'Net 8/35/6 (SS & DS)
- ElectroNet 9/35/12 (SS & DS)
- ElectroNet Plus 9/35/12 (DS)
- HogNet 4/18/12 (SS)
- HogNet 10/24/12 (SS)
- RaccoonNet 4/18/12 (SS)
- VersaNet 9/20/3 (SS)
- VersaNet Plus 9/20/3 (SS)
- VersaNet 11/30/3 (SS)
- VersaNet Plus 11/30/3 (SS)

Repair Kit #201710

- E'Stop 9/42/6 (SS & DS)
- ElectroStop 10/42/12 (SS & DS)
- ElectroStop Plus 10/42/12 (DS)
- PoultryNet 12/42/3 (SS & DS)
- PoultryNet Plus 12/42/3 (DS)
- PoultryNet 12/48/3 (SS & DS)
- PoultryNet Plus 12/48/3 (DS)

Repair Kit #201720

- Horse QuikFence 4/48/24 (DS)

Repair Kit #201721

- Cattle QuikFence 4/28/24 (DS)
- Deer QuikFence 5/60/12 (DS)
- Pig QuikFence 6/30/12 (SS)
- Sheep QuikFence 6/35/24 (DS)

Repair Kit #201730

- Bear QuikFence 11/35/12 (DP)
- ElectroFence 11/48/12 (SS & DS)
- ElectroFence Plus 11/48/12 (DS)
- ElectroNet 9/35/12 (DP)
- PermaNet 10/48/6 (SS & DS)
- PermaNet Plus 12/48/3 (SS & DS)
- PermaNet 12/68/6 (DS)
- PermaNet 19/68/3 (DS)
- PoultryNet 12/42/3 (DP)
- PoultryNet 12/48/3 (DP)
- ElectroStop 10/42/12 (DP)
- VersaNet Plus 12/60/3 (DS)

Repair Kit #201740

- Chicken Net 12/42/3 (SS)
- Chicken Net 12/48/3 (SS)
- Goat & Sheep Net 9/42/6 (SS)
- Sheep & Goat Net 8/35/6 (SS)

www.premier1supplies.com • 800-282-6631 • Washington, IA 52353