

# SupaReel - Assembly Instructions

#238000

## To assemble the carry handle and brake

1. Remove nut, bolt, brass brake and one of the washers from the handle.
2. Slide reel onto handle. There should be a washer separating the reel from the spring.
3. Place second washer onto handle. Reattach bolt, brass brake and nut. Tighten nut enough to provide security while still letting the brake operate.

## To assemble windup handle

1. Remove white plastic nut from the bolt on the windup handle.
2. Remove metal nut and bolt from the black windup handle.
3. From the inside of the reel, place the bolt through the reel at the nut-shaped hole.
4. Screw on metal nut from the outside of the reel, tighten metal nut to the reel.
5. Place black windup handle over bolt.
6. Screw on white plastic nut.

## To use the brake

Flip the brass brake to apply pressure to the reel and lock it into place.



[www.premier1supplies.com](http://www.premier1supplies.com)

800-282-6631

Washington, IA 52353

© Copyright 2017, Premier1Supplies. All rights reserved.