

Netting Repair Kits

Repair Kit #201700

- ElectroNet 9/35/12 (SS & DS)
- ElectroNet Pro 9/35/12 (SS)
- ElectroNet Plus 9/35/12 (DS)
- HogNet 4/18/12 (SS)
- HogNet 10/24/12 (SS)
- PigletNet Plus 11/30/3 (SS)
- RaccoonNet 4/18/12 (SS)
- VersaNet Plus 9/20/3 (SS)
- VersaNet Plus 11/30/3 (SS)

Repair Kit #201710

- ElectroStop 10/42/12 (SS & DS)
- ElectroStop Plus 10/42/12 (DS)
- PoultryNet 12/42/3 (SS & DS)
- PoultryNet Plus 12/42/3 (DS)
- PoultryNet 12/48/3 (SS & DS)
- PoultryNet Plus 12/48/3 (DS)

Repair Kit #201720

- Horse QuikFence 4/48/24 (DS)

Repair Kit #201721

- Cattle QuikFence 4/28/24 (DS)
- Deer QuikFence 5/60/12 (DS)
- Pig QuikFence 6/30/12 (SS)
- Sheep QuikFence 6/35/24 (DS)

Repair Kit #201730

- Bear QuikFence 11/35/12 (DP)
- ElectroFence 11/48/12 (SS & DS)
- ElectroFence Plus 11/48/12 (DS)
- ElectroNet 9/35/12 (DP)
- PermaNet 10/48/6 (SS & DS)
- PermaNet Pro 11/48/6 (DP)
- PermaNet Plus 12/48/3 (SS & DS)
- PermaNet 12/68/6 (DS)
- PermaNet 19/68/3 (DS)
- PoultryNet 12/42/3 (DP)
- PoultryNet 12/48/3 (DP)
- ElectroStop 10/42/12 (DP)
- VersaNet Plus 12/60/3 (DS)

Repair Kit #201740

- Chicken Net 11/42/3 (SS)
- Chicken Net 12/48/3 (SS)
- Goat & Sheep Net 10/42/7 (SS)
- Sheep & Goat Net 9/35/7 (SS)

© Copyright 2017, Premier1Supplies.
All rights reserved.

How to repair netting if a horizontal wire is broken:

STEPS:

1. Disconnect from power source. Snip the broken ends of the horizontal wire.
2. Measure out enough replacement conductor to cover gap and tie knots.
3. Tie the replacement material to each side of the break with square knot.
4. Place a brass ferrule over each of the square knots and clamp together with a pair of pliers.



www.premier1supplies.com

800-282-6631