


Pickup Hauler Assembly Instructions


#967000
#967001




1. Connect panel B to panel A with a 40" connector hinge.



2. Connect the second B panel to the A panel, use a 40" hinge.




3. Connect the second A panel to one of the B panels with a 40" hinge. Use two snap clips to connect the remaining corner.



4. Place panel C onto the top of the rear side of the hauler frame. Connect 36" sides to the A panel with 36" hinges.




5. The 48" side connects via a 48" hinge to panel B.



6. Place second C panel onto the hauler. Connect to A panel with remaining 36" hinge.



7. Connect the 48" sides of the C panel with the 48" hinge.



8. Connect the C panel to B panel (door) with remaining snap clip.



9. Tie down appropriately (*tie downs not included*).

For the small pick up hauler, the 2 C panels are one panel instead of two. Assembly is the same for both.

Note: Pickup hauler was assembled on the ground to demonstrate assembly. In normal use, the hauler would be assembled in the back of a pickup.



www.premier1supplies.com
800-282-6631
Washington, IA
© Copyright 2016, Premier1Supplies.
All rights reserved.