Prima Heat Lamp Instructions #557100



1. Place dome over top of lamp (as shown).



2. Line up the holes in top of dome with those in the lid. Insert screws and tighten.



3. Cut/remove cable ties (they are not heat resistant).

Operational Instructions

- 1) Insert desired bulb—maximum 250 watts. Both red and clear infrared bulbs can be used.
- 2) Close plastic mesh guard by twisting the grill clockwise, into the frame.

Two options to do so:

- **a.** Hold the frame beneath one arm, and twist the grid clockwise with both hands.
- **b.** Firmly hold the lamp/frame between your legs (while sitting down). Use both hands to twist the grid clockwise into place.
- 3) Hang as required with a secure fastener. Select height to match the situation. The recommended <u>minimum</u> distance from the lamp to the ground or lamb/kid is 20". Can be lowered a few extra inches when used with chicks.

RISK OF ELECTRICAL SHOCK.
Connect only to a branch
circuit protected by a ground-fault circuitinterrupter (GFCI). Contact a qualified
electrician if you cannot verify that the circuit
is protected by a GFCI.

To ensure safety, please self-inspect the plug and connection (or ask a certified electrician to do so).

© Copyright 2017 Premier1Supplies. All rights reserved.



