


GameCrate™

#540160




www.premier1supplies.com
800-282-6631

© Copyright 2019, Premier1Supplies.
All rights reserved.



1. Install corner supports in corners.
A mallet (see inset above) may be needed for encouragement.



2. Doors can be placed on sides or ends. Make sure door pin fits into frame.



3. Set top onto crate. Align all holes and pins.



4. Tap the top into place.