



4000s Shearing Head Parts

Item No.	Part No.	Description
01	82900401	1 - Tension nut
02	82900402	1 - Sliding sleeve
03	82900403	1 - Tension lock spring
04	82900404	1 - Lid bushing
05	82900405	1 - Shearing head (without accessories)
06	82900406	1 - Plastic head cover
07	82900407	1 - Head cover screw
08	82900408	1 - Fork guide bracket
09	82900409	1 - Fork plate
10	82900410	1 - Fork finger (right)
11	82900411	1 - Fork finger (left)
12	82900412	1 - Comb screw
13	82900413	1 - Fulcrum lock nut
14	82900414	1 - Countersunk head screw
15	82900415	1 - Toothed washer
16	82900416	1 - Fulcrum post screw
17	82900417	1 - Tension spring plate
18	82900418	1 - Crank roller
19	82900419	1 - Crank spindle shaft
20	82900420	1 - Bearing
21	82900422	1 - Spindle hub with fibergear
22	89600610	2 - Head screws and 2 washers (sold as a set)



110v 4000



Cord Socket
89500480

Phillips Screw
89900490

Cord Strap
89500450

Ball Bearing, rear
88000550

Plastic Plug
828060

O Ring, back
89500290

Disk Spring
89100700

Circuit Board
8280070

Disk for Drive
89500390

Phillips Screw
89900490

1 Brush & 1 Spring
89500430

Armature
8280073

Brush Guide
89500260

FV Fan
89911370

Ball Bearing, front
87100400

Stator
8280074

Lower Housing
89911351A

Phillips Screw
89900490

Square Nut
89900400

O Ring, front
89500310