


70 Amp Hr. Assembly Instructions

Lay the two 35 amp hr batteries in lower case on IntelliShock unit (32B, 55B and 88B). By hooking the battery's parallel (Positive to Positive and Negative to Negative) we achieve a 70 amp hr. battery.



www.premier1supplies.com

800-282-6631

2031 300th St., Washington, IA 52353

© Copyright 2017, Premier1Supplies. All rights reserved.