
## **Ascot Feeders**

- 1. Place feeder cone in base and twist so the tabs of the feeder lock into tabs of the base.
- 2. Snap metal hanger into cut outs on the inside top of the feeder.
- 3. Push legs onto base of feeder. Narrow end of leg fits onto base.
- 4. **To use without rain hat**, place lid onto the feeder. Line up slots in the lid over the wire hanger.
- 5. **To use with rain hat**, remove small lid and place rain hat onto feeder. Line up slots in the rain hat over the wire hanger.

Your feeder is ready to use. Remove lid or rain hat to fill with feed.

## #540026 - 5.5 lb without grill #540028 - 5.5 lb with grill #540030 - rain hat





800-282-6631 www.premier1supplies.com