

## Clipping Blades— how to attach to your clipping head...




Premier clipper, without the blade set attached.



Clipper blade set. Top and bottom blades.



Unscrew tension nut/spring (A) from tension bolt (B).



Place blue guide over crank spindle and into slots of head.



Place the bottom blade over the blade guides.



Insert tension bolt (B) through the bottom blade.



Thread tension nut/ spring (A) onto tension bolt (B). Hand tighten until spring is fully compressed. Then untighten 2 full turns.



This is how your clipper should look with clipper blades attached.

Remember: oil the tips of your blades every 2-3 minutes.



Oil the following:

- 1. The round drive.
- 2. Tips of the upper and lower blades—every 2–3 minutes.
- 3. Guide blocks/stainless inserts.



www.premier1supplies.com 800-282-6631

© Copyright 2014, Premier1Supplies. All rights reserved.