


Marking Crayon Insertion Instructions



1. Marking crayon in plastic crayon protector.




2. Cut the label in the middle to reveal the metal cotter pin. The plastic pins are provided loose.



3. Turn holder back over and take the plastic cap off (protects crayon during transport).




4. Slide the crayon into the harness by inserting the narrow end first.



cotter pin

plastic pins



4. Metal Cotter Pin - Take the cotter pin and push all the way through the middle holes of the harness. Once the cotter pin is pushed through all the way bend back the ends flush with the crayon.

5. Plastic Pins (optional) - Use instead of the cotter pin. Push pins in holes on each side of harness.



800-282-6631

www.premier1supplies.com

Washington, IA

© Copyright 2016, Premier1Supplies.

All rights reserved.