

How to install...

1. Insert (post A) into the docking station as shown. Press post and docking station into the ground next to netting (endpost 1).
2. Tap in skewers.
3. Zip-tie (post A) to netting (endpost 1).
4. Insert (post C) next to netting (endpost 2).
5. Zip tie (post C) to (end post 2).
6. Insert (post B) into docking station.
7. Lock handles together.
8. Make electrical connections.



One of the HotGate posts (without a spike) fits into docking station. This enables you to easily open and close the gate.