

Saturn 15 Feeder

Item #530035



www.premier1supplies.com • 800-282-6631

© Copyright 2016, Premier1Supplies. All rights reserved.

To Assemble:

- 1) Lower tower portion over base.
- 2) Align holes in tower with the desired pegs that are on the base. Push tower directly down and over pegs once they are aligned.
- 3) Fill feeder with feed. Place cover on top. Either hang or set the feeder in the desired location.

If the speed at which the feed is coming out is either too slow or fast, try using the other peg height settings available on the base. There are four settings in total.

To remove the tower from the base, use a screwdriver or similar tool to gently pry the tower away from the base. This is rigid plastic and if abused, it can crack. Please use caution if you decide to adjust the feed flow rate.

Any questions, please feel free to contact Premier.