

# Prima Heat Lamp®



**Prima Heat Lamp®**  
**#557100**  
120V AC 60 Hz  
250 WATT MAX  
CLEAR OR RED R40 LAMP

**Replacement**  
**#5571015**



**Premier1Supplies**  
premier1supplies.com  
800-282-6631

©Copyright 2020 Premier1Supplies, LLC.  
All rights reserved.

## WARNING! FIRE HAZARD/IMPORTANT SAFETY INSTRUCTIONS.

**WARNING:** Disconnect power before replacing lamp bulb or cleaning. Not intended for hose spray down.

**WARNING:** For use with heat lamp only to warm lambs, goat kids, chickens, ducks, puppies or for any animal that is sick or cold. Not for human use. May cause serious burns. Do not use over sensitive skin areas or in the presence of poor circulation. The unattended use of infrared heat by children or incapacitated persons may be dangerous.

**WARNING:** May cause serious burns. Do not use over sensitive skin areas or in the presence of poor circulation. The unattended use of infrared heat by children or incapacitated persons may be dangerous.

**WARNING:** Hot surface. Avoid contact.

**CAUTION:** Mount minimum 20" above surface for operation.

**CAUTION:** Do not operate without protective grill/guard.

**CAUTION:** Do not use in the proximity of vehicles or when there is a risk of flammable liquids coming into contact with this product.

**CAUTION:** Do not submerge this product. For dry indoor use only. Do not use in hazardous locations.

**CAUTION:** To reduce the risk of fire use 250 watt or smaller.

**CAUTION:** This product has a polarized plug (one blade is wider than the other) as a safety feature. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, turn the plug over and try again. If it still does not fit, contact a qualified electrician. Never use an extension cord unless the plug can be fully inserted. **DO NOT ATTEMPT TO DEFEAT THIS SAFETY FEATURE.**

**⚠ WARNING RISK OF ELECTRICAL SHOCK.** Connect only to a branch circuit protected by a ground-fault circuit-interrupter (GFCI). Contact a qualified electrician if you cannot verify that the circuit is protected by a GFCI.

To ensure safety, please self-inspect the plug and connection (or ask a certified electrician).



- 1) Insert desired bulb—maximum 250 watts. Both red and clear infrared bulbs can be used.
- 2) Close plastic mesh guard by pushing down on the grill and twisting clockwise, into the frame (similar to using a childproof bottle cap).

### Two options to do so:

- a. Hold the shade beneath one arm, push and twist the grill clockwise with both hands.
- b. Firmly hold the shade between your legs (while sitting down). Use both hands to push and twist the grill clockwise into place.

- 3) Hang as required with a secure fastener. Select height to match the situation. The minimum distance from the lamp to the ground or lamb/kid is 20".