



CORRECT POSITIONING OF THE SENSOR PROBE IN THE BIOTIC OVIS-40 AUTOMATIC FEEDER

The sensor probe's position in the mixing bowl is important for the reliable operation of the OVIS-40 Automatic Feeder.

The tip of the probe must be positioned about 1/2" above the top edge of the nut which sits on the left side wall of the mixing bowl. The sensor probe should have at least 1/2" bare metal on the end. Make sure that sensor probe tip does not touch the walls of the mixing bowl. Please make sure to check for the correct positioning after cleaning and maintenance.

