

Instruction of the Portable Electronic Scale

Description

- Portable Electronic Scale base on application- embedded microcomponent core, with accurate weight, functional stable and digital LCD display etc. Additinally, it include lots of features, Tare/Net weight is standard; Professional accuracy; Zero(Tare) feature; Show weight in dwt;gn;ct and Automatic power-off. It is excellent scale of family / shopping weight and easy to carry.

Power on:

- Put the scale at vertical position without weight in hook
- Press "ON/OFF" key, the screen will display (8888)
Wait for 2-3 seconds until the (0.00 or 0.000) displaying on the screen. The scale will be ready for weighing.

Tare/Zero

- Put the container on hook when weighing bulk goods.
Press "TARE" key, and the screen will display "0.00 or 0.000".
The scale is ready for weighing.
Put the goods to the container. The screen will display the weight of the goods only after finishing.

Weight Lock

- Press "TARE" key for 2 seconds until the "L_ON" or "L_OF" sign appearing on the screen.
- Press POWER again to weight new objects. "
- "L_ON" stands for weight lock enable which means weight of the article will be fixed on the screen. "L_OF" stands for weight lock function disable.

Weighing

- Hook in the goods after the scale is ready.
- Max weight shall not exceed full 55kg.
- The screen will display "O-Ld".
- The scale will hold the weight of the goods automatically.
display "HOLD" or " " in the "L_on" mode.

Unit selection:

Press "UNIT" key to select the unit. The unit could be selectable among kg, lb, jin, oz (1kg=2.2lb=2jin=35oz).

Temperature test:

- Press UINT key for 2 seconds. The temperature will appear on the screen. The tolerance of temperature is $\pm 2^{\circ}\text{C}$. Press "ON/OFF" to exit the temperature test mode


Power off:

- Press "ON/OFF" key to turn off under weighing (without "HOLD") mode.
- Press "ON/OFF" key to clear the "HOLD" sign, and press "ON/OFF" key again to turn off under the "HOLD" mode.
- Press "ON/OFF" to exit the temperature test mode, press "ON/OFF" key to turn off under the temperature mode.
- The electronic scale will auto turn off in 120 seconds if there is no operation.

*BACKLIGHT FUNCTION(BACKLIGHT EDITION):

Backlight will be extinguished after 5 seconds without any pushbutton operation or weight be changed. Backlight will be illuminated when touch any pushbutton or change the weight.

Caution:

- Vertical position required for turn on or self test.
- To keep the weight accuracy and protect the scale, please hold the stationary ring straight or add some additional tools on the stationary rings when weighing. Don't hold the plastic casing when weighing.
Avoid any strong shock or vibration during operation.
- Use clean water and wash detergent for cleaning. Do not use the corrosive liquid (such as ad benzene, nitrate solvent, caustic soap etc.) to clean the case of the scale since it is made by ABS plastic.
When the screen appears the sign (), it means the batteries are exhausted and need to be replaced. Remove the batteries to avoid leakage and damage to the circuits if the scale is not used for a long time.
- Do not disassembly the scale yourself in case the product needs to be repair. Please contact our agent for assistant.