

Premier Heat Lamp Instructions

- 1) Insert desired bulb - max. 250 watts. Both red & clear infrared bulbs can be used.
- 2) Close plastic mesh guard.

Note: To keep animals safe from the bulb, a strong and very secure plastic latch is used. This latch will require a tool unless the user has strong hands. Repeated use will make the task easier by flexing the plastic and learning the technique.

- a. Squeeze white plastic mesh together. (See photo 1.)
 - b. Place over orange latches.
 - c. Release finger pressure to secure guard. (See photo 2.)
- 3) Hang as required with a secure fastener. Select height to match the situation. The recommended minimum distance from the lamp to the ground or lamb/kid is 20".

To ensure safety please self-inspect the plug and connection (or ask a certified electrician to do so.)



Photo 1




Photo 2



800-282-6631
www.premier1supplies.com

Washington, IA

Heat Lamp Replacement Parts

