


Permanent - Rope fence up to 5 strands

Click on the products and photos below to view on our website.



www.premier1supplies.com

800-282-6631 • Washington, IA



C. 5-Light Tester

D. Insulated Cable

G. Conductor

H. Galv. Steel T Post

I. Premier Hot Top Ins.

J. Premier Combo Ins.

K. Corner Post Ins.

L. Wood Line Post Ins.

To install

1. Install end, corner & line posts.
2. Attach insulators to posts.
3. Attach rope to one end post.
4. Clip rope into insulators.
Pull until the P Spring is 50% compressed. Terminate it.
5. Connect ropes electrically at one end with an insulated wire or a Rope-to-Rope Link.
6. Install and connect the energizer. Voltage should be over 1500 volts. The fence must always be properly electrified.

Fence diagram

| Product Name | Item |
|---|---------|
| A. Energizers | |
| B. Galv. Ground Rod, 6' x 5/8", 6 lb. | #151000 |
| Stainless Clamp, 0.10 lb | #151800 |
| C. 5-Light Tester, 0.30 lb | #200006 |
| D. Insulated Cable | |
| E. Warning Sign, 0.06 lb | #346000 |
| F. Cut-Out Switch, 0.32 lb | #333000 |
| G. EnduraSoft 6.0, 660', 12 lb | #256500 |
| IntelliRope PE 6.0, 660', 8.20 lb | #256900 |
| IntelliBraid, 660', 11.60 lb | #256710 |

| Product Name | Item |
|---|---------|
| H. Galv. Steel T Post, 7', 10.50 lb | #327800 |
| I. Premier Hot Top Ins., 0.20 lb | #381000 |
| J. Premier Combo Ins., 0.10 lb | #380321 |
| K. Corner Post Ins., 0.20 lb | #380900 |
| L. Wood Line Post Ins., 0.10 lb | #380712 |
| M. P Spring Combination | |
| 1. TuffRing II Ins., 0.10 lb | #380705 |
| 2. P Spring, SS, 0.30 lb | #255010 |
| 3. RopeLink 2.6, 0.10 lb | #256210 |

M. P Spring Combination with RopeLink

